



# PRO ARMOR

## CAN-AM COMMANDER FABRIC ROOF

To avoid injury to your self or damage to the vehicle, read these instructions carefully before installation.

### 1. Parts List:

Item	Part Name	Description	Qty
1	Roof	Fabric	1

### 2. Installation:

- a) Position fabric roof over the Commander roll cage with seams facing in and the wider portion to the rear.
- b) Secure the fabric roof to the roll cage by rapping the velcro straps around the tubing of the roll cage at each attachment point. See fig. below.
- c) Adjust the fabric roof where necessary so that it covers the entire top portion of the roll cage and so that it is centered.

**3. Maintenance:** Check to see that all straps are secured to the roll cage.

**4. Care and Cleaning:** Clean with cold water and air dry.

**5. Customer service:** For further information call Pro Armor at 951-343-9270



Wrap and fasten velcro straps around roll cage tubing at rear, side, and cross member attachment point locations.