



POLARIS RZR XP (P111041) ALUMINUM REAR BUMPER INSTALLATION INSTRUCTIONS

Please read these instructions carefully before installation to prevent injury to yourself or damage to your vehicle.

PARTS LIST:

ITEM	DESCRIPTION	QTY
1	FRONT BUMPER	1

HARDWARE KIT:

ITEM	DESCRIPTION	QTY
2	M8 x 20mm BOLT	6
3	M8 NUT	6

PREPARATION:



INSTALLATION:



POSITION THE REAR BUMPER IN PLACE AND INSTALL THE SPECIFIED HARDWARE

MAINTENANCE:

Periodically check to see that the rear bumper is properly installed. Re-torque mounting bolts when necessary. Do not operate the vehicle if any bolts or fasteners are loose or missing.

CUSTOMER SERVICE:

For further information, please contact Pro Armor at 1-951-343-9270

P111041