



PRO ARMOR

INSTRUCTIONS

Kawasaki Teryx750

Front A-Arm Skid Plates

To avoid injury to your self or damage to the ATV, read these instructions carefully before installation.

1. Parts List:

Item	Part Name	Description	Qty
1	K082020-01	Left A-Arm Guard	1
2	K082020-02	Right A-Arm Guard	1

2. Preparation:

- a) Lock the vehicle's rear parking brake to prevent movement during installation.
- b) Remove the OEM plastic A-Arm covers retaining the mounting hardware.

3. Installation:

- a) Position the left A-Arm guard under the left A-Arm aligning the mounting holes of the guard to those located on the A-Arm of the vehicle.
- b) Secure the A-arm guard to the vehicle by re-installing the retained mounting hardware.
- c) Repeat procedures 1-2 for the right A-Arm guard on the right side of the vehicle.

4. Maintenance: Check all fasteners and re-torque when required.

5. Care and Cleaning: Clean using a soft cloth with soap and water.

6. Customer service: For further information please call Pro Armor at 1-951-343-9270.

K082020