



PRO ARMOR®

XP1000 Spare Tire Mount (P141061)

Installation Instructions

Installation Instructions:

1. Make sure the bed area is cleared out and nothing is connected in the way of the spare tire mount when it's mounted.
2. Remove the four(4) cage bolts that connect the cage to the chassis with the tube connector bungs and set the mount in place like shown below and hand tighten the bolts. You will not need to hold the nut on the backside since the bungs are designed to lock this nut in place and only need to tighten from the outside once the nut is locked in place.
3. Once the mount is fully tightened, hook the quick shot with 2 hook straps on the lower side, like show in figure below. Set the tire in place and lift the quick shot back over the tire and connect a single hook strap to the top loop on the mount like shown below. Check each strap to make sure they adjusted where there is no movement in the tire when shaken. It's best to keep the QS centered and keep the wide side straps shorter than the single strap on the narrow side. This will leave room to cinch it down. Check straps before each use!



WARNING

Please read: This product is sold without warranty expressed or implied. No warranty or representation is made as to the products ability to protect the user / occupant from any injury or death in any manner of use. *The user assumes that risk.* The effectiveness of this equipment is directly related to the manner in which it is installed, used, and / or maintained. **Proper installation is solely the responsibility of the installer, and will not be assumed by Pro Armor.**

For further information on installation instructions and warnings please visit our website WWW.PROARMOR.COM or contact customer service at 1-888-31-ARMOR

For further information on installation instructions and warnings please visit our website WWW.PROARMOR.COM or contact customer service at 1-888-31-ARMOR